

Electrical equipment for potentially explosive atmospheres.

Understanding the marking of an equipment intended for use in hazardous areas is often difficult. INERIS gives here some keys to compare marking issued from international, north american and european standards in the field of explosion protection.

Ex marking

IEC	US (NEC 505)		US (NEC 500	CENELEC	
Explosion protected I.S. output Group Gas group Ex d [ia] IIC T5 Method of protection Temperature class	Class I, Zone I, AEx d [ia] Permitted zone I.S. o	Gas group Gus group TIC T5 utput ature class P	Nethod of protection (optional except for I.S.) Explosionproof with I.S. Ou Division I, Groups A,I Permitted go Permitted division (optional except for division 2)	B,C,D,T5	European standard, Method of protection, Group EEx d [ia] IIC T5 I.S. output Gas group Explosion protected Temperature class

Area classification

IEC	Flammable material	Flammable material	Flammable material	
	Present continuously	Present intermittently	Present abnormally	
CENELEC	Zone 0	Zone 1	Zone 2	
	(Zone 20 - Dust)	(Zone 21 - Dust)	(Zone 22 - Dust)	
US NEC 505	Zone O	Zone 1	Zone 2	
NEC 500	Divisi	Division 2		

Training

INERIS technical courses:

- Provide you the essential knowledges about the ATEX European compliance in order to obtain the Fmarking.
- Analyse the key elements of the other new approach directives as Electromagnetic Compatibility or Machinery directives.

(Training on your site or at INERIS).

Marking

According to the ATEX directive

Equipment group II (other than mines)

Category 1 (for zone 0 or 20) 2 (for zone 1 or 21) 3 (for zone 2 or 22)

G for gases, vapours and mist

D for dusts

Equipment group I

Category M1 and M2

notified body

INERIS (*) is one of the notified bodies in European Union approved to carry out the conformity assessment procedures for equipment in hazardous areas. It can assist designers, manufacturers and users of such equipment. INERIS can also assume tests in order to obtain an overseas certification (Factory Mutual in States or CANMET in Canada, ...).

(*) INERIS steaming from CERCHAR







The following figures inform you about relations between international applicable standards concerning protection methods and their applications according to hazardous areas classification.

Class I, Zone O, 1 and 2 Protection Methods

Olus	JI, ZOIIC C		<u>u </u>	0.000.	CII IVIC	111000
		Applicable Certification Standards				
Area	Protection Methods	UL	FM	CSA	IEC	CENELEC
Zone 0	Intrinsically safe, "ia"Class I, Div. 1Intrinsically safe method	UL 2279, Pt.11 ANSI/UL 913	FM 3610	CSA-E79-11 CSA-157	IEC 79-11	EN 50020
Zone 1	 Encapsulation "m" Flameproof "d" Increased safety "e" Intrinsically safe "ib" Oil immersion "o" Powder filling "q" Purged/pressurized "p" Any Class I, Zone 0 method Any Class I, Div. I method 	UL 2279, Pt.18 UL 2279, Pt.1 UL 2279, Pt.7 UL 2279, Pt.11 UL 2279, Pt.6 UL 2279, Pt.5 UL 2279, Pt.2	FM 3614 FM 3618 FM 3619 FM 3610 FM 3621 FM 3622 FM 3620	CSA-E79-18 CSA-E79-1 CSA-E79-7 CSA-E79-11 CSA-E79-6 CSA-E79-5 CSA-E79-2	IEC 79-18 IEC 79-1 IEC 79-7 IEC 79-6 IEC 79-5 IEC 79-2	EN 50028 EN 50018 EN 50019 EN 50020 EN 50015 EN 50017 EN 50016
Zone 2	 Nonincendive "NI" Non-sparking device "nA" Restricted breathing "nR" Hermetically sealed "nC" Any Class I, Zone O or 1 method Any Class I, Div. 1 or 2 method 	UL 2279, Pt.15 UL 2279, Pt.15 UL 2279, Pt.15 UL 2279, Pt.15 	FM 3611	CSA-E79-15 CSA-E79-15 CSA-E79-15 CSA-E79-15	IEC 79-15 IEC 79-15 IEC 79-15 IEC 79-15	EN 50021 EN 50021 EN 50021 EN 50021

INERIS resources and facilities

Agreement, certification and evaluation

- Equipment and protective systems intended for use in potentially explosive atmospheres.
- Equipment used in underground part of mines.
- Safety components.
- Protective personal equipment.
- Explosives of civil uses.
- Machines for the manufacture of pyrotechnics.
- Explosive products and fireworks.
- Opacity sensors metrology.

Other services

- Risks due to electrostatic effects and lightning.
- Routine tests according to international certification standards (IEC,...) and others requirements.
- Training.
- Assistance to users: risks analysis, area classification,...

Full scale laboratory trials

- Testing equipment assuming temperatures until -50°C.
- Ingress protection test chamber until 8m³.
- Type tests of electrical and non-electrical equipment for use in explosion-hazardous areas (intrinsic safety, protection by enclosures,...).
- Large scale facilities: fire test cell, explosive firing ranges, dust explosion cells, fire development chambers, anechoic chamber.



Class 1

Flammable gases, vapors or liquids

Area classification

■ Division 1 and Zone 0

Where ignitable concentrations of flammable gases, vapors or liquids can exist all of the time or some of the time under normal operating conditions.

Zone 1

Where ignitable concentrations of flammable gases, vapors or liquids can exist some of the time under normal operating conditions.

Division 2 and Zone 2

Where ignitable concentrations of flammable gases, vapors or liquids are not likely to exist under normal operating conditions.

Groups

Division 1 and 2

- A (Acetylene)
- B (Hydrogen)
- C (Ethylene)
- D (Propane)

■ Zone 0, 1 and 2

- **IIC** (Acetylene & Hydrogen)
- IIB (Ethylene)
- IIA (Propane)

Class 2

Combustible dusts

Area classification

Division 1

Where ignitable concentrations of combustible dusts can exist all of the time or some of the time under normal operating conditions.

Division 2

Where ignitable concentrations of combustible dusts are not likely to exist under normal operating conditions.

Groups

Division 1 and 2

- **E** (Metals)
- F (Coal)
- **G** (Grain)

Class 3

Ignitable fibers & flyings

Area classification

Division 1

Where ignitable concentrations of ignitable fibers and flyings can exist all of the time or some of the time under normal operating conditions.

Division 2

Where ignitable concentrations of ignitable fibers and flyings are not likely to exist under normal operating conditions.

Groups

Division 1 and 2

None



Ingress Protection (IP)

FIRST NUMBER			SECOND NUMBER					
	Protection against solid bodies			Pr	rotection against liquid			
0 1 2 3 4 5 6 7 8	No protection Objects greater than 50 mm Objects greater than 12 mm Objects greater than 2,5 mm Objects greater than 1 mm Dust-protected Dust-tight			No protection Vertically dripping water 75° to 90° dripping water Sprayed water Splashed water Water jets Powerfull water jets Temporary immersion Continuous immersion				
	APPROXIMATE US ENCLOSURE TYPE EQUIVALENT TO IPXX							
	Type ➤ 1 2 3 3R	1P 10 11 54 14	Type 3S 4 & 4X 5	5	5	Type ► 6 & 6P 12 & 12K 13	67 52 54	

Apparatus Grouping

Apparatus Grouping						
TYPICAL GAS	US (NEC 505) IEC CENELEC	US (NEC 500)				
Acetylene Hydrogen Ethylene Propane Methane	Group IIC (Group IIB + H ₂) Group IIB Group IIA Group I	Class I / Group A Class I / Group B Class I / Group C Class I / Group D Gassy mines				
Maximum surface Temperature	US (NEC 505) IEC CENELEC	US (NEC 500)				
300°C 280°C 260°C	T1	T2 T2A T2B				
200°C 180°C 165°C 160°C	T4					
135°C 120°C 100°C 85°C	T4 T5 T6	T4A				

Reciprocal agreements

Factory Mutual Research

1151 Boston-Providence Turnpike P.O. Box 9102 Nordwood MA 02062-9102

U.S.A. Tel: 781 255 4840 Fax: 781 762 9375

Approvals@factory-mutual.com

ANMET - CERL (Canada Center for Mineral and Energy Technology)

Natural Resources, Canada **Canadian Explosives Research** Laboratory c/o 555 Booth street

OTTAWA, ONTARIO. CANADA K1A 0G1

Tel: 613 996 1902 Fax: 613 996 2597 e.mail: mcote@rncan.gc.ca

Budapest Mikoviny Samuel)

u.2-4 H1037 PF 115

H.1300 Budapest . HUNGARY Tel /Fax: 36 1 250 17 20 e.mail: bkiex@elender.hu

Glowny Instytute Gornictwa)

Central Mining Institute Plac Gwarkow n°1 40166 Katovice . POLAND Tel: 48 32 581 631 Fax: 48 32 596 533

gig@boruta.gig.katovice.pi

André Mallet
Tel: +33 (0)3 44 55 65 43
e-mail: Andre.Mallet@ineris.fr

Bernard Piquette
Tel: +33 (0)3 44 55 65 44
e-mail: Bernard.Piquette@ineris.fr

Alain Czyz
Tel: +33 (0)3 44 55 65 42
e-mail: Alain.Czyz@ineris.fr